20-year warranty

View our full warranty:
polywoodoutdoor.com/warranty

Having trouble?

If you have questions or concerns regarding assembly instructions or missing parts, please contact us at **hello@polywoodoutdoor.com** or **(833) 665-6300**

Cleaning tips

For a Quick Clean:
Simply wipe down with soap and water.

For a Deep Clean:
Wipe on ⅓ bleach and ⅔ water solution with a clean cloth and let it sit on the lumber for a few minutes (this will not affect the color). Then, loosen any dirt and debris that may catch in surface grooves with a soft bristle brush; hose down to rinse.

For a High-Power Clean:
Use a pressure power washer (not exceeding 1,500 psi) to spray off dirt and debris. Apply a ⅓ bleach and ⅔ water solution and scrub with a soft-bristle brush. Hose down to rinse.

06/03/2019

POLYWOOD

Assembly Instructions



GN23X
Vineyard Deep Seating Chair

polywoodoutdoor.com

Thank You

Thank you for choosing POLYWOOD!
We hope our furniture helps create a gathering place for you and your loved ones to enjoy for many years to come!

Reach Out

Let us know how we're doing:
hello@polywoodoutdoor.com
(833) 665-6300

Stay Connected

Be the first to hear about new products, giveaways, and more by signing up for our email list: **polywoodoutdoor.com/subscribe**

Watch & Learn

For assembly tips and videos visit:
polywoodoutdoor.com/assembly

Share your space

We love to see where our furniture ends up — snap a pic and tag it on Instagram or Facebook for your chance to be featured on our social channels!
#polywood #rethinkoutdoor

facebook.com/polywoodoutdoor

@POLYWOOD

pinterest.com/polywood

youtube.com/polywood



Did you know?

POLYWOOD was the original outdoor furniture made from recycled materials.

Learn more about our story:
genuinePOLYWOOD.com

TOOLS



4mm T-handle
hex key (included)

Phillips Screwdriver
(Screw Gun Recommended)
(Not Included)

PARTS





1.75″ Screw — H.27X1.75



3″ Screw — H.27X3



2″ Phillips Screw — H8X2

Something missing?
Call (833) 665-6300

1



Position screw through back leg
and align with pilot hole in the arm
Duplicate other side

2



3



4



5





POLYWOOD

POLYWOOD

Assembly Instructions



NO ASSEMBLY REQUIRED

CT22

Newport 22" End Table

20-Year Warranty

To view our full warranty, please visit **polywoodoutdoor.com/warranty**

Easily register your product using one of the methods below:

Text POLYWOOD to 71403
Receive a link to register online

— or —

Register on our website
register.polywoodoutdoor.com

— or —

Send a Picture
Take a photo of the icon below and text it to 71403 (US only)

PHOTOREGISTER℠
POLYWOOD

Having Trouble?

If you have questions or concerns regarding assembly instructions or missing parts, please contact us at **(833) 665-6300** or email **support@polywoodoutdoor.com**

Share your space

We love to see where our furniture ends up — snap a pic and share it on Instagram or Facebook!
#polywood

Watch & Learn

For assembly videos and more, visit **youtube.com/polywood**

Cleaning Tips

Even POLYWOOD gets dirty — here are some ways to help keep it clean:

For a quick clean:
Simply wipe down with soap and water.

For a deeper clean:
You'll need:

» ⅓ bleach and ⅔ water solution
» clean cloth
» soft bristle brush

Wipe on solution with your cloth and let it sit on the lumber for a few minutes (this will not affect the color). Then, loosen any dirt and debris that may catch in surface grooves with a soft bristle brush; hose down to rinse.